

How to use Tyre and your Interphone GPSBike device? *For use with Ndrive software*

Tyre is the best software to use if you want to use itinerary files on your Interphone GPSBike device.

There are three steps to follow:

1. Create or open a route in Tyre and copy it to your device.
2. Import the route on your device.
3. Activate the route on your device.

These steps are described in this short manual.


1. Create or open a route in Tyre and copy it to your device.

This short manual does not describe how to create or open a route in Tyre. Read the Tyre FAQ or the Tyre help pages to find out more about that:

FAQ: <http://www.tyretotravel.com/help/>


Help pages: <http://www.tyretotravel.com/tyredata/help6/english/>

Connect your device to your computer in the 'USB disk mode':



Tyre will recognize your device and will switch to 'Interphone mode' for cooperation with your device.

You can recognize the 'Interphone mode' very easily: in the main menu, the 'TomTom' item will change into 'Interphone'.



If you want to copy your itinerary to your device, just select 'Copy to Interphone' from that menu.

On the button bar, there is also a button that can do it for you. (Just move your mouse over the buttons and read the hints, until you see a hint that says 'Copy to Interphone'.)

That is all. The itinerary file is on your device. Now it must be imported and opened on the device itself.

NOTE:

Here is some other thing that you have to keep in mind. Your device uses the Google KML format for route files. This file type can be saved in different ways. If you want it to be saved properly, even when you save the file on your computer, keep your device connected to your computer.

Each time that a KML file is going to be saved, Tyre checks whether there is a Interphone GPSBike device connected to your computer. If that is the case, the KML file will be saved in a format that suits the needs of your device.

2. Import the route on your device.


- If your device is connected to your computer, disconnect it.
- Turn on the device, when it is off.
- Select 'Navigation'.




- After entering the navigation, the navigation main screen will be shown. From the lower right corner, tap 'Menu':



- Select these options in succession: 'My NDrive', 'Data Import/Export', 'Import Itineraries':



- Now you see a list of files on your device, from which you can import your itineraries; select the one you want to import:



- After importing is done, you will return to the previous screen automatically. From there you return to the main screen by tapping the globe in the upper right corner.




3. Activate the route on your device.

Once you have returned to the main screen, the only thing you have done, is importing the itinerary, which means that the system is able to find it. It is not active yet. That is the next action to perform.


- From the main screen, tap 'Menu' in the lower right corner.



- Select these option in succession: 'Go To' and 'Itineraries':



- Now you are offered a list of available itineraries that you can select for navigating.



- Have fun!